

TRM-006A-


Event output 1

Option

Power supply

TRM-006A- -A

■ Panel cutting and outside dimension



■ Panel mounting

